

APPLICATOR PARTS LIST				TYPE LENGTHWISE RING AMPLIVAR			WIRE TRIM <b>AMP</b> AMP Incorporated Harrisburg, PA 17105-3608		CRIMPING DATA		TERMINALS
NO.	DESCRIPTION	REQ.	PART NO.	NO.	DESCRIPTION	REQ.	PART NO.				
1	▲ WIRE CRIMPER .218	1	1-453925-1	42	▲ WIRE TRIMMER	1	811264-2	TO APPLY TERMINAL		62755	
2	▲ INS. CRIMPER	-	-	43	-	-	-	WIRE SIZE CRIMP HEIGHT		63332	
3	▲ ANVIL	1	2-473405-1	44	-	-	-	12	.086	-	
4	ANVIL INSERT	1	-	45	SPACER, GUARD .265	2	375569	-	-	-	
5	▲ SHEAR BLADE	1	4-465233-2	46	-	-	-	(2) 15	.087	-	
6	▲ REAR SHEAR PLATE	1	385013-4	47	-	-	-	-	-	-	
7	SHEAR BLADE SPACER	2	374083	48	-	-	-	14	.078	-	
8	▲ FRONT SHEAR PLATE	1	376637	49	HOLD DOWN (BLADE MT)	1	467261-1	CRIMP	SIZE	TYPE	FEED
9	REAR ANVIL SPACER PL	1	1-470857-5	50	WASHER	3	371178	WIRE	.180	F	1.015
10	FRONT ANVIL SPACER PL	1	375430	51	ID TAG	1	452373-1	INSUL.	-	-	
11	TOOL SPACER	2	1-470493-3	52	DRIVE SCRS	3	21017-6	SLEEVED	-	-	
12	CRIMP SPACER	-	-	53	-	-	-	INSULATION RANGE		WIRE RANGE	
13	FRONT STRIP GUIDE	1	1-472438-7	54	-	-	-	-	-	14-12 OR (2) 15	
14	REAR STRIP GUIDE	1	1-472438-8	55	-	-	-	EXPLODED VIEW			
15	RAM	1	471167	56	-	-	-	A-5000	A-6000-3		
16	TOOL HOLDER	1	376046	57	-	-	-	REMARKS:			
17	ADJ. CRIMP MOUNT	-	-	58	-	-	-	▲ RECOMMENDED SPARE PARTS			
18	ADJ. BLOCK	-	-	59	-	-	-	▲ MT. ITEM 71 & 72 IN EXH.			
19	APPLICATOR MOUNT ASSY.	1	471445	60	-	-	-	PORT OF QUICK EXH. VALVE			
20	BASE PLATE	-	-	61	-	-	-	OF AIR FEED ASSY (ITEM 64).			
21	BASE BLOCK	-	-	62	-	-	-	3 TOP TOOL MT, 5, 11, 11, 42 & 1.			
22	STRIP GUIDE PLATE	-	-	63	-	-	-				
23	ANVIL HOLDER	1	370526	64	2" AIR FEED ASSY	1	690021				
24	AUX. ANVIL HOLDER	1	377515	65	TENSION ADJ. PLATE	1	374999				
25	▲ STRIPPER	1	811265-3	MISCELLANEOUS							
26	STRIPPER MOUNT	2	386231	66	AIR BLAST ASSY	1	455350-1				
27	RETAINER PLATE	2	372251	67	ELBOW, MALE	1	22317-3				
28	STRIPPER MOUNT BRACKET	-	-	68	TUBING, COPPER	1	689446-2				
29	STRIPPER BUSHING	-	-	69	LUBRICATOR ASSY	1	465184-2				
30	STOCK DRAG	1	375381	70	SYNTHETIC OIL	REF	22014-1				
31	STOCK DRAG HANDLE	-	-	71	▲ HEX NIPPLE	1	22304-4	THIS APPLICATOR IS TO BE USED ON			
32	STOCK DRAG STUD	2	354045-1	72	▲ FLOW CONTROL VALVE	1	23054-1	AMP-O-ELECTRIC 1-471273-2			
33	STOCK DRAG SPRING	2	1-23847-1					AIR FEED			
34	STOCK DRAG ADJ. SCREW	2	372997					ALIGN GA. 679597-1			
35	FEED FINGER HOLDER	-	-					SERIAL NO.	DATE SHIPPED		DR. 1-8-91 M. YOUNGER
36	FEED FINGER	1	375093					CUSTOMER NAME AND ADDRESS			CHK'D 10-25-92 KENSINGER
37	FEED FINGER TIP	-	-								APP'D
38	FEED FINGER STUD	-	-		J	ECN A-395892	TB	9-92			
39	BASE CASTING	1	570238		H	ECN A-364692	LK	5-92			
40	GUARD, ASSY	1	457664-7		G	REDWN ECN A-283390	LK	10-90			
41	-	-	-		P F LTR	REVISION RECORD	APP	DATE			

LOC A DIST 4

LOG NO 566273-1 SHEET 1 OF 1 REV J